



NOTES:

1. ALL FITTINGS ARE MALLEABLE IRON THREADED FITTINGS AND SHALL BE WRAPPED.
2. REMOVE COMBINATION BLOWOFF SAMPLING TAP ASSEMBLY AFTER COMPLETION OF DISINFECTION, REPLACE COUPLING PLUG.
3. INSTALL VALVE BOX COVER AFTER COUPLING PLUG IN PLACE.

REV. 08/01

Dublin San Ramon Services District	DATE MAY 1987
COMBINATION BLOWOFF AND SAMPLING TAP FOR 2" TO 3" BLOWOFF (TEMPORARY INSTALLATION)	DESIGNED RMR
SIGNED COPY ON FILE AT DISTRICT OFFICE	DRAWING W-18